

SIM800 Series_GSM Location_Application Note_V1.01



Document Title:	SIM800 Series_GSM Location_Application Note	
Version:	1.01	
Date:	2015-03-12	
Status:	Release	
Document Control ID:	SIM800 Series_GSM Location_Application Note_V1.01	

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Shanghai SIMCom Wireless Solutions Ltd, copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2015



Contents

1	Intr	oduction	4
2	AT (Commands	5
	2.1		5
	2.2	AT+CLBSCFG	6
3	Exa	mples	8
	3.1		8
	3.2	Get Location	8
	3.3	Report Really Location	9
	3.4	Deactivate Bearer Profile	9
Аp	pendi	ix	10
	A F	Related Documents	10



Version History

Date	Version	Description	Author
2014-09-24	1.00	New version	ZhuDingFen
2015-03-12	1.01	Modify CLBS format	ZhuDingFen
		Modify catalogue error	
		Add AT+CLBS=3,1 example	

Scope

This document presents the AT command of GSM location operation and application examples. This document can apply to SIM800 series modules with GSM location function, that the SW version will include "LBS" characters.



Introduction 1

This chapter introduces the GSM location feature of SIM800 series modules





AT Commands

2.1 AT+CLBS

AT+CLBS Base sta	tation Location	
Test Command	Response	
AT+CLBS=?	+CLBS:	
	(1,3,4,9),(1-3),(-180.000000-180.000000),(-90.000000-90.000000),(0,1)	
	ок	
	Parameters	
	See Write Command	
Write Command	Response	
AT+CLBS= <type>,</type>	OK	
$<\!\!\operatorname{cid}\!\!>,\!\![[<\!\operatorname{longitude}\!\!>,$	1)type = 1,get longitude and latitude	
<latitude>],[<lon_ty< th=""><th>+CLBS: <locationcode>[,<longitude>,<latitude>,<acc>]</acc></latitude></longitude></locationcode></th></lon_ty<></latitude>	+CLBS: <locationcode>[,<longitude>,<latitude>,<acc>]</acc></latitude></longitude></locationcode>	
pe>]]		
	OK	
	2)type = 3,get access times	
	+CLBS:	
	<locationcode>[,<times>]</times></locationcode>	
	OK	
	3)type = 4,get longitude latitude and date time	
	+CLBS:	
	<locationcode>[,<longitude>,<latitude>,<acc>,<date>,<time>]</time></date></acc></latitude></longitude></locationcode>	
	ОК	
	4)type = 9, report positioning error	
	+CLBS: <locationcode></locationcode>	
	OK	
If error is related to ME functionality:		
	+CME ERROR: <err></err>	
	Parameters	
	<type></type>	
	1 use 3 cell's information	
	3 get access times	
	4 get longitude latitude and date time	



		9 report positioning error
	<cid></cid>	network parameters, refer to AT+SAPBR
	<locationcode></locationcode>	> 0 Success
	1	If the operation failed, the location code is not 0, such as:
		1 Location Failed
		2 Time Out
		3 NET Error
		4 DNS Error
		5 Service Overdue
		6 Authenticate Failed
		7 Other Error
		80 Report LBS to server success
		81 Report LBS to server parameter error
		82 Report LBS to server failed
	<loopitude></loopitude>	Current longitude in degrees
	<latitude></latitude>	Current latitude in degrees
	<acc></acc>	Positioning accuracy
	<lon_type></lon_type>	The type of longitude and latitude
	<u>0</u>	WGS84, the default type
	1	GCJ02
	<times></times>	access service times
	<date></date>	service date
	<time></time>	service time
Reference	Note	
	If custome	rs feel that the positioning error is too large, <type></type>
	=9 can be used	to report this information, we will improve this error by
	this information	1.

2.2 AT+CLBSCFG

AT+CLBSCFG Base station Location configure			
Test Command	Response		
AT+CLBSCFG=?	+CLBSCFG: 0,(1-2),''ParamValue''		
	OK		
	Parameters		
	See Write Command		
Write Command	Response		
AT+CLBSCFG=<0	+CLBSCFG: 0, <para>,<value></value></para>		
perate>, <para></para>			
	OK		
	If error is related to ME functionality:		



	+CME ERROR: <err></err>	
	Parameters	
	<operate> 0 read operator</operate>	
	<pre><para> 1 customer ID</para></pre>	
	2 times have used positioning command	
	<value> the value of parameter</value>	
Reference	Note	



3 **Examples**

SIM800 GSM location module provides GSM location solution. The following is the examples for application.

In the "Grammar" columns of following tables, input of AT commands are in black, module return values are in blue.

3.1 Activate Bearer Profile

Grammar	Description
AT+SAPBR=3,1,"Contype","GPRS" OK	Set bearer parameter
AT+SAPBR=3,1,"APN","CMNET" OK	Set bearer context
AT+SAPBR=1,1 OK	Active bearer context
AT+SAPBR=2,1 +SAPBR: 1,1,"10.89.193.1" OK	Read bearer parameter

3.2 Get Location

, ,	
Grammar	Description
AT+CLBSCFG=0,1	Get customer ID
+CLBSCFG: 0,1,"CUSTES"	
OK	
AT+CLBSCFG=0,2	Get Times have used positioning command
+CLBSCFG: 0,2,0	
OK	
AT+CLBS=1,1	Get current longitude , latitude and Precision
+CLBS: 0,121.359505,31.217055,637	
OK	
AT+CLBS=3,1	Get access times
+CLBS: 0,1280	
OK	



AT+CLBS=4,1	Get current longitude , latitude , Precision
+CLBS:	and date time
0,121.359505,31.217055,637 ,14/11/03,10:09:00	
OK	

3.3 Report Really Location

Grammar	Description
AT+CLBS=9,1 +CLBS: 80	If the position info is error, customer can use this command to report. Report cell information of positioning error to server
OK	
AT+CLBS=9,1,121.360046,31.218135,0 +CLBS: 80	Report cell information of positioning and really longitude and latitude to server
OK	

3.4 Deactivate Bearer Profile

Grammar	Description
AT+SAPBR=0,1	Deactivate bearer context
OK	



Appendix

A Related Documents

SN	Document name	Remark
[1]	SIM800 Series AT Command Manual	
		$\langle \lambda \rangle$
		~ 10
		$\langle \lambda \rangle$
		Y



Contact us:

Shanghai SIMCom Wireless Solutions Co.,Ltd.

Address: Building A, SIM Technology Building, No. 633, Jinzhong Road, Shanghai,

P. R. China 200335 Tel: +86 21 3252 3300 Fax: +86 21 3252 3020 URL: www.sim.com/wm